



Mars Labs
29 C Street
Laurel, MD 20707

June 1, 2015

Document # SB-1282

Service Bulletin

TCS - Titan Control Software v3.1.7

Applicability: This new release is recommended for all Titan product users.

Description: Titan Control Software (TCS) version 3.1.7 incorporates the following feature enhancements and bug fixes:

1. Implemented Multi-Plot Data Review feature that provides user-selectable plotting of grouped analog and digital data types
2. Implemented inverted gain selections to provide polarity inversion *
3. Improved GPS sync performance when used with multiple Titan devices
4. Corrected export issue with CPU GPS/PPS data (PPS data now included)
5. Added acknowledgement (ACK) enable function to the Digital Pod configuration
6. Fixed 'blank screen' error that occurred with embedded help when loading a configuration file that was not located in the Mars Labs directory.

* Inverted gains are only supported on Titan devices with firmware version 0.34.20 or higher installed.

TCS v3.1.7 is available as an *Installer* that includes all required support files as well as an update to the embedded User Manual that provides context-sensitive help.

Update: Download TCS v3.1.7 from the Mars Labs Knowledge Base:

<http://marslabs.com/wiki/doku.php>

Note that you will need a login name and password to download the update – please contact Mars Labs to obtain login credentials if you have not already been supplied the information.

Help: For additional information or assistance, please contact:

Mars Labs
Phone: 301-470-3278
Email: support@marslabs.com
www.marslabs.com